


Scope of delivery



- > 6 ActiveBands | 65 cm each

2 x blue	2,5 - 4,5 kg
2 x red	4,5 - 6,5 kg
2 x black	6,5 - 9,0 kg
- > 2 padded handles
- > 2 straps with carabiner hooks
(can also be used as leg-loops)
- > 1 doorframe anchor
- > 1 useful bag

Thanks to the door anchor, you can even use your Active Bands without the PowerBoard. The door anchor can be attached to the height between the door and the doorframe depending on your exercise. Once applied with care, the stopper is located on one side and the loop on the other.

NOTE! The Door may be damaged if the ActiveBand Set is used incorrectly.

Disposal note

In accordance with waste regulations, the ActiveBands and all packaging components can be disposed of at the waste company or at an organization responsible for disposal.

Cleaning | Maintenance | Storage

1. Recommended storage: dry, free of dust.
2. Keep liquids and open fire away.
4. Be sure to rinse out the cloth multiple times when wiping down.
5. Allow the ActiveBands dry naturally.

EU-Conformity declaration

Corresponds to the European guidelines ROHS2011/65/EU.

Warranty conditions

The retailer guarantees a statutory period of warranty for the product described on the reverse.

Warranty is valid from the date of purchase. The purchase date must be documented with proof of purchase. The retailer will repair or replace free-of-charge all items covered in Germany for which faults have been discovered. A prerequisite is that you send the faulty device with proof of purchase before the guarantee or warranty period expires. The warranty claim shall not be applicable if a fault is established which has arisen e.g. due to external influences or as a consequence of a repair or modification which was not carried out by the manufacturer or an authorised dealer.

The following points are not part of the warranty:

- Wear caused by improper use
- Commercial use e.g. exhibition use, repeated use without intermediate breaks of 40 minutes
- Exposing the device to heat, humidity of liquids
- Damage due to sharp and/or sharp-edged objects
- Wanton destruction, misappropriation, overloading or accidental damage
- Damage and soiling by domestic animals
- Contamination caused by body or hair care products
- Damage caused by use of acids, solvent or alcohol agents

The warranty granted by the retailer is limited to repair and exchange of the product. Under this warranty, the manufacturer or the retailer shall have no further liability and are not responsible for damages that have arisen due to disregard of the operating instructions and /or improper use of the product. Where upon examination of the product by the manufacturer it is found that the warranty request does not concern a defect covered by the warranty or that the warranty period has expired, the customer must bear the costs for the inspection and repair.

As manufacturer, Casada ensures the delivery of faultless goods to buyers/partners. Proven production faults are entitled to an exchange after registration and confirmation. Legal note: All contents do not contain healing statements. The diagnosis and treatment of illnesses and other physical disorders require a treatment by a physician, non-medical practitioner or therapist. The statements are strictly informative and may not be used as a substitute for a professional medical treatment. Every user is beholden to ascertain by accurate examination and, if required, after consultation of a specialist, if the application is the right one for their specific cases. Each dose or application takes place at the risk of the user. We dissociate ourselves from any healing statements or promises.

Casada International GmbH
Obermeiers Feld 3
33104 Paderborn, Germany
info@casada.com
www.casada.com

Copyright Images and texts are subject to the copyright of Casada International GmbH and may not be used for other purposes without express confirmation.

Copyright © 2019 Casada International GmbH. All rights reserved.